

January 27, 2008

How to run L1Cal_I Ib_GUI on d0tcc3

On any online node:

```
ksu d0cal  
setup d0online  
cd ~d0l1/projects/l1cal2b  
./bin/run_tcc_gui
```

This may have privilege issues.

Alternate ways: Log on (ssh or otherwise) to d0tcc3

1)

On TCC3:

```
/mnt/home/mulhearn/bin/run_gui
```

Or

2)

(after ssh d0l1@d0tcc3)

```
/mnt/home/d0l1/scripts/run_gui_from_d0tcc3
```

They all point to:

```
/tcc/L1Cal_I Ib_Work/L1Cal_I Ib_TCC/linux/build/run_gui
```

The GUI looks as shown below:

